

ACCESSORIES PROGRAM



7030-100 DRINKING GUIDE, R 1/2" - SS - P

A common problem with all watering valves is that the animals bite the valves from the side. When the animals bite the valve from the side it creates unnecessary water spillage. The AquaGlobe drinking guide forces the animals to drink right in front of the valves and therefore reduces water spillage. The guide can be fitted in existing installations or added to completely new installations. All parts are made from high grade stainless steel and the pipe threads are the common 1/2" size.

7020-100 ADJUSTABLE WALL BRACKET, R 1/2" - SS - P

With the adjustable wall bracket the height of the valve can be adjusted to the height of the animal as it grows. It is very important to have the right height to avoid unnecessary water spillage. If the valve is placed too high or too low it is hard for the animals to grasp the valve in a natural way. The bracket has a hex screw that can be loosened to allow adjusting. All parts are made from high grade stainless steel and the pipe threads are the common 1/2" size.



7010-100 WALL BRACKET 15 DEGREES R 1/2" - SS - B

The AquaGlobe wall bracket is made with the optimal angle of 15 degrees to reduce water spillage. The bracket is made from high grade stainless steel and the pipe threads are the common 1/2" size.

7110-100 PIPE 500 MM, R 1/2" - SS - P

7110-100 PIPE 750 MM, R 1/2" - SS - P

7110-100 PIPE 1000 MM, R 1/2" - SS - P

The pipes are installed from the bracket and up to a level where the animals can't reach. They prevent the animals from gnawing on the water lines with their teeth. The pipes are made from high grade stainless steel and the pipe threads are the common 1/2" size.

